



# **Beauty Culture**

Advanced Probiotic  
Skin Care System





Harness the power of probiotics to improve the health and beauty of the skin. Cultured dairy products have been used for centuries to improve the appearance of the skin. It has even been said that Cleopatra bathed in milk to leave her skin feeling soft and smooth.

Yogurt bioferment increases intracellular metabolism and cellular respiration. Skin cells function more efficiently. Studies confirm that yogurt bioferment improves collagen production and fibroblast proliferation. These benefits may be useful in cosmetic and personal care products to improve the skin's integrity and elasticity making it appear healthy and revitalized.

**Beauty Culture** - a personal care line delivering probiotic benefits to the skin. Active ingredients for optimal results!

**Smoothing Bamboo Body Lotion:** Natural bamboo bio-silicates leave a luxurious, smooth sensation.

**Softening Pomegranate Body Butter:** Rich and creamy. Drives moisture into the skin. Pomegranate Sterols leave the skin hydrated and moist.

**Brightening Lemon Under Eye Crème:** Fermented capsicum fruit increases microcirculation. Alleviates puffiness. Lemon peel extracts lighten under eye circles.

**Purifying Rice Facial Cleanser:** Mild lather. Rice extracts gently clean and rejuvenate the skin.

**Invigorating Cocoa Body Scrub:** Sugarcane gently exfoliates. Cocoa leaves the skin feeling smooth and re-awakened.

## Beauty Culture

Advanced Probiotic  
Skin Care System



**Smoothing Bamboo Body Lotion**  
**+ Yogurt Bioferment**  
**+ Bamboo Bioferment**



Smoothing Bamboo Body Lotion delivers probiotic benefits of yogurt. Improves cellular respiration and metabolism. Leaves the skin feeling soft and smooth.



**Beauty Culture**  
Advanced Probiotic Skin Care System

# Beauty Culture

Advanced Probiotic Skin Care System



## Smoothing Bamboo Body Lotion: FNBB01-91 Yogurt Bioferment + Bamboo Bioferment

Ingredient	Trade Name/Vendor	%
<b>Phase I</b>		
Water	Water	QS
Salix Alba ( <i>Willow</i> ) Bark Extract	<b>ABS White Willow Bark Extract Powder/ Active Concepts, LLC</b>	2.00
Sodium Phytate	Dermofeel PA-3/Kinetik Technologies	0.20
Butylene Glycol	Butylene Glycol	2.50
Carbomer	Ultrez 10/Protameen	0.50
<b>Phase II</b>		
Glycerin	Glycerin	2.00
Carrageenan	Viscarin PC 209/Earth Supplied Products	0.75
<b>Phase III</b>		
Tocopherol Acetate	Rita Vitamin E Acetate/Rita Corp.	0.50
Glyceryl Stearate	Protachem GMS 450/Protameen	4.00
Stearic Acid	Stearic Acid/Rita Corp.	2.00
Beeswax	Beeswax/Strahl & Pitsch	0.50
Isopropyl Palmitate	Rita IPP/Rita Corp.	0.50
Cetyl Alcohol	Cetyl Alcohol/Rita Corp.	2.25
Butyrospermum Parkii ( <i>Shea Butter</i> )	Shea Butter/Kinetik Technologies	1.50
Simmondsia Chinensis ( <i>Jobba</i> ) Seed Oil	Clear Jojoba Oil/Arista	2.50
Helianthus Annuus ( <i>Sunflower</i> ) Seed Oil	Sunflower Oil/Arista	2.50
<b>Phase IV</b>		
Lactobacillus/Arundinaria Gigantea Ferment Extract	<b>ACB Bamboo Bioferment/ Active Concepts, LLC</b>	10.00
<b>Phase V</b>		
Water	Water	2.00
Triethanolamine	TEA 99%/Rita Corp.	0.30
<b>Phase VI</b>		
Lactobacillus Bulgaricus Ferment Filtrate	<b>ACB Yogurt Dermal Respiratory Factor/ Active Concepts, LLC</b>	4.00
<b>Phase VII</b>		
Glycerin	Glycerin	5.00
Leconostoc Kimchii ( <i>Radish</i> ) Root Ferment Filtrate	<b>AC Leucidal/Active Concepts, LLC</b>	0.50
<b>Phase VIII</b>		
Fragrance	Lavender & Vanilla Sage 302669/ American Flavors & Fragrances	0.30

### Process Instructions:

**Phase I:** Charge water into main beaker and begin propeller mixing. A vortex should form. Begin heating to 75°C. Sift in ABS White Willow Bark Extract Powder Charge Dermofeel PA-3. Charge Butylene Glycol. Sift in Ultrez 10.

**Phase II:** Pre-blend and add to main.

**Phase III:** In a separate container, blend ingredients and heat to 80°C. Once temperatures have been reached, add to main. Maintain temperature of 78°C and continue mixing for 15 minutes.

**Phase IV:** Remove heat. Add at 60°C. • **Phase V:** Begin force cooling. Pre-blend and add to main.

**Phase VI:** Add at 45°C. • **Phase VII:** Pre-blend and add to main. • **Phase VIII:** Add to main.



Tomorrow's vision ... Today!

+1-732-867-5040 • Fax: +1-732-867-5041 • activeconceptsllc.com

**Softening Pomegranate Body Butter**  
**+ Yogurt Bioferment**  
**+ Pomegranate Sterols**

Softening Pomegranate Body Butter effectively hydrates and moisturizes. Delivers the advantages of probiotics. Increased cellular respiration and cellular metabolism improves the overall healthy look of the skin.



**Beauty Culture**  
Advanced Probiotic Skin Care System

# Beauty Culture

Advanced Probiotic Skin Care System



## Softening Pomegranate Body Butter: FNBB01-98

*Yogurt Bioferment + Pomegranate Sterols*

Ingredient	Trade Name/Vendor	%
<b>Phase I</b>		
Water	Water	QS
Salix Alba ( <i>Willow</i> ) Bark Extract	<b>ABS White Willow Bark Extract Powder/</b> <b>Active Concepts, LLC</b>	2.00
Sodium Phytate	Dermofeel PA-3/Kinetik Technologies	0.20
Glycerin	Glycerin	7.00
<b>Phase II</b>		
Caprylic/Capric Triglycerides	Ritamollient CCT/Rita Corp.	2.00
Stearic Acid	Stearic Acid/Rita Corp.	0.50
Cetearyl Alcohol (and) Cetareth 20	Procol CS-20-D/Protameen	5.00
Glyceryl Stearate	Protachem GMS 450/Protameen	4.00
Cocoa Butter	Cocoa Butter/Protameen	7.00
Butyrospermum Parkii ( <i>Shea Butter</i> )	Shea Butter/Kinetik Technologies	5.00
Carthamus Tinctorius ( <i>Safflower</i> ) Seed Oil	Safflower Oil/Arista	2.00
Tocopheryl Acetate	Rita Vitamin E Acetate/Rita Corp.	0.50
Persea Gratissima ( <i>Avocado</i> ) Oil	Avocado Oil/Arista	2.00
Prunus Amygdalus Dulcis ( <i>Sweet Almond</i> ) Oil	Almond Oil/Arista	2.00
Punica Granatum ( <i>Pomegranate</i> ) Sterols	<b>ABS Pomegranate Sterols/Active Concepts, LLC</b>	5.00
Rubus Chamaemorus Seed Oil	<b>AC Cloudberry Seed Oil/Active Concepts, LLC</b>	2.00
Beeswax	White Beeswax/Strahl & Pitsch	0.50
Rosa Canina Fruit Extract	<b>ABS Rose Hips Extract OS/Active Concepts, LLC</b>	1.00
<b>Phase III</b>		
Lactobacillus/Arundinaria Gigantea Ferment Extract	<b>ACB Bamboo Bioferment/</b> <b>Active Concepts, LLC</b>	7.00
<b>Phase IV</b>		
Sodium Hydroxide	NaOH 25% Solution	0.25
<b>Phase V</b>		
Glycerin	Glycerin	5.00
Leconostoc Kimchii ( <i>Radish</i> ) Root Ferment Filtrate	<b>AC Leucidal/Active Concepts, LLC</b>	0.50
<b>Phase VI</b>		
Lactobacillus Bulgaricus Ferment Filtrate	<b>ACB Yogurt Dermal Respiratory Extract/</b> <b>Active Concepts, LLC</b>	5.00
Fragrance	Lavender & Vanilla Sage 302669/ American Flavors & Fragrances	1.00

### Process Instructions:

**Phase I:** Charge water into main beaker and begin propeller mixing. A vortex should form. Begin heating to 75°C. Sift in ABS White Willow Bark Extract Powder. Charge Dermofeel PA-3 and Glycerin.

**Phase II:** In a separate beaker, blend ingredients together and heat to 80°C. Once temperatures have been reached, add to main tank. Maintain temperature of 78°C and continue mixing for 15 minutes. • **Phase III:** Remove heat. Add at 60°C.

**Phase IV:** Add at 55°C. • **Phase V:** Begin force cooling. Pre-blend and add to main. • **Phase VI:** Add to main.



Tomorrow's vision ... Today!

+1-732-867-5040 • Fax: +1-732-867-5041 • [activeconceptsllc.com](http://activeconceptsllc.com)

## Brightening Lemon Under-Eye Crème

+ Yogurt Bioferment

+ Lemon Peel Extract

+ Capsicum Fruit Bioferment

Brightening Lemon Under Eye

Crème helps reduce the appearance of dark circles.

Fermented capsicum fruit and yogurt bioferment potentiate the lightening effects of lemon peel extract.



**Active  
Concepts**

**Beauty Culture**

Advanced Probiotic Skin Care System

## Beauty Culture

Advanced Probiotic Skin Care System



### Brightening Lemon Under-Eye Crème: FNFB01-96

*Yogurt Bioferment + Lemon Peel Extract + Capsicum Fruit Bioferment*

Ingredient	Trade Name/Vendor	%
<b>Phase I</b>		
Water	Water	QS
Salix Alba ( <i>Willow</i> ) Bark Extract	<b>ABS White Willow Bark Extract Powder/ Active Concepts, LLC</b>	2.00
Glycerin	Glycerin	2.00
Sodium Phytate	Dermofeel PA-3/Kinetik Technologies	0.20
Carbomer	Ultrez 10/Protameen	0.50
<b>Phase II</b>		
Cetearyl Alcohol (and) Ceteareth-20	Procol CS-20-D/Protameen	3.00
Olea Europaea ( <i>Olive</i> ) Fruit Oil	Olive Oil/Arista	1.00
Stearic Acid	Stearic Acid/Rita Corp.	2.00
Simmondsia Chinensis ( <i>Jojoba</i> ) Seed Oil	Jojoba Oil Clear/Arista	1.00
Stearyl Alcohol	Rita SA/Rita Corp.	1.50
Butylene Glycol Dicaprylate/Dicaprate	Dermofeel BGC/Kinetik Technologies	1.00
<b>Phase III</b>		
Lactobacillus/Arundinaria Gigantea Ferment Extract	<b>ACB Bamboo Bioferment/ Active Concepts, LLC</b>	1.00
<b>Phase IV</b>		
Lactobacillus/Citrus Medica Limonum ( <i>Lemon</i> ) Peel Ferment Extract (and) Butylene Glycol	<b>ACB Lemon Peel Extract/ Active Concepts, LLC</b>	2.00
Saccharomyces/Capsicum Annum Fruit Ferment Filtrate	<b>AC DermaPeptide Micro C/ Active Concepts, LLC</b>	0.50
Lactobacillus Bulgaricus Ferment Filtrate	<b>ACB Yogurt Dermal Respiratory Factor/ Active Concepts, LLC</b>	5.00
Ascorbic Acid	<b>Stabilized Vitamin C/Active Concepts, LLC</b>	0.50
<b>Phase V</b>		
Glycerin	Glycerin	5.00
Leconostoc Kimchii ( <i>Radish</i> ) Root Ferment Filtrate	<b>AC Leucidal/Active Concepts, LLC</b>	0.50
<b>Phase VI</b>		
Fragrance	Lavender & Vanilla Sage 302669/ American Flavors & Fragrances	0.25

#### Process Instructions:

**Phase I:** Charge water into main beaker and begin propeller mixing. A vortex should form. Begin heating to 75°C. Sift in ABS White Willow Bark Powder Extract. Charge Glycerin and Dermofeel PA-3. Sift in Ultrez 10.

**Phase II:** In a separate container, blend ingredients and heat to 80°C. Once temperatures have been reached, add to main. Maintain temperature of 78°C and continue mixing for 15 minutes.

**Phase III:** Remove heat. Add at 60°C.

**Phase IV:** Add each at 45°C. Slowly sift in Stabilized Vitamin C.

**Phase V:** Pre-blend and add to main.



Tomorrow's vision ... Today!

+1-732-867-5040 • Fax: +1-732-867-5041 • [activeconceptsllc.com](http://activeconceptsllc.com)

**Purifying Rice Facial Cleanser**  
**+ Yogurt Bioferment**  
**+ Rice Amino Acids**



Purifying Rice Facial Cleanser gently washes the face. Rice amino acids hydrate and refresh the skin. Yogurt bioferment improves cellular functions. Leaves skin looking healthy and renewed.



**Beauty Culture**

Advanced Probiotic Skin Care System

## Beauty Culture

Advanced Probiotic Skin Care System



### Purifying Rice Facial Cleanser: FNFB01-97 *Yogurt Bioferment + Rice Amino Acids*

Ingredient	Trade Name/Vendor	%
<b>Phase I</b>		
Water	Water	QS
Salix Alba ( <i>Willow</i> ) Bark Extract	<b>ABS White Willow Bark Extract Powder/ Active Concepts, LLC</b>	2.00
Sodium Phytate	Dermofeel PA-3/Kinetik Technologies	0.20
<b>Phase II</b>		
Sodium Laureth Sulfate	Steol CS-130/Stepan	30.00
Sodium Lauryl Sulfoacetate (and)		
Disodium Laureth Sulfosuccinate	Stepanmild LSB/Stepan	18.00
Cocamidopropyl Betaine	Amphosol CA/Stepan	10.00
Cocamidopropyl Hydroxysultaine	Chemron CAS/Chemron	5.00
<b>Phase III</b>		
Sodium Cocoyl Hydrolyzed Rice Protein	<b>AC Foaming Rice/Active Concepts, LLC</b>	3.00
Rice Amino Acids	<b>AC Rice Amino Acids/Active Concepts, LLC</b>	2.00
Water & Butylene Glycol & Oryza Sativa ( <i>Rice</i> ) Flower Extract	<b>ABS Rice Flower Extract/Active Concepts, LLC</b>	2.00
Yogurt Extract (and) Lactobacillus Bulgaris Lysate Extract	<b>ACB Yogurt Dermal Respiratory Factor/ Active Concepts, LLC</b>	5.00
<b>Phase IV</b>		
Glycerin	Glycerin	5.00
Leconostoc Kimchii ( <i>Radish</i> ) Root Ferment Filtrate	<b>AC Leucidal/Active Concepts, LLC</b>	0.50
<b>Phase V</b>		
Fragrance	Lavender & Vanilla Sage 302669/ American Flavors & Fragrances	0.25
PEG-150 Pentaerythrityl Tetrastearate (and) PEG-6 Caprylic/Capric glycerides (and) Water	Crothix Liquid/Croda	0.45

#### Process Instructions:

**Phase I:** Charge water into main beaker and begin propeller mixing. A vortex should form. Begin heating to 70°C. Sift in ABS White Willow Bark Extract Powder. Charge Dermofeel PA-3.

**Phase II:** Switch to sweep mixing. Once temperature has reached 70°, charge each ingredient individually. Continue mixing for 15 minutes. • **Phase III:** Begin force cooling. Add each at 50°C.

**Phase IV:** Pre-blend and add to main at 45°C. • **Phase V:** Add to main.



Tomorrow's vision ... Today!

+1-732-867-5040 • Fax: +1-732-867-5041 • [activeconceptsllc.com](http://activeconceptsllc.com)

## **Invigorating Cocoa Body Scrub**

- + Yogurt Bioferment**
- + Cocoa Bioferment**
- + Sugarcane**

Invigorating Cocoa Body Scrub wakes up your skin. Sugarcane naturally exfoliates. Cocoa has anti-inflammatory properties. Improves cell turnover and evens skin tone. Yogurt bioferment brings out the skin's natural beauty.



**Beauty Culture**

Advanced Probiotic Skin Care System

## Beauty Culture

Advanced Probiotic Skin Care System



# Invigorating Cocoa Body Scrub: FNBB01-86

*Yogurt Bioferment + Cocoa Bioferment*

Ingredient	Trade Name/Vendor	%
<b>Phase I</b>		
Water	Water	QS
Salix Alba ( <i>Willow</i> ) Bark Extract	<b>ABS White Willow Bark Extract Powder/ Active Concepts, LLC</b>	2.00
Sodium Phytate	Dermofeel PA-3/Kinetik Technologies	0.20
Carbomer	Ultrez 10/Protameen	1.40
<b>Phase II</b>		
Water	Water	2.00
Triethanolamine	TEA 99%/Rita Corp.	0.70
<b>Phase III</b>		
Disodium Laureth Sulfosuccinate	Mackanate EL/Chemron	3.00
Sodium Lauryl Sulfate	Standapol ES-3/Cognis	5.00
Cocamidopropyl Hydroxysultaine	Chembetaine CAS/Chemron	2.50
<b>Phase IV</b>		
Phoenix Dactylifera ( <i>Date</i> ) Seed	<b>Date Seed Powder/Active Concepts, LLC</b>	10.00
Polyethylene	Asensa SC 201/Honeywell	5.00
Simmondsia Chinesis ( <i>Joboba</i> ) Butter (and) Hydrogenated Jojoba Oil	Jojoba Butter Beads/Desert Whale	2.50
<b>Phase V</b>		
Lactobacillus Bulgaricus Ferment Filtrate	<b>ACB Yogurt Dermal Respiratory Factor/ Active Concepts, LLC</b>	5.00
Water (and) Saccharium Officinarium Extract Lactobacillus/Theobroma Cacao ( <i>Cocoa</i> ) Fruit Ferment Filtrate	<b>ABS Sugarcane Extract/Active Concepts, LLC</b>	2.00
Water & Butylene Glycol (and) Cocos Nucifera ( <i>Coconut</i> ) Extract	<b>ACB Cocoa Bioferment/Active Concepts, LLC</b>	3.00
<b>Phase VI</b>		
Glycerin	<b>ABS Coconut Milk/Active Concepts, LLC</b>	2.00
Leconostoc Kimchii ( <i>Radish</i> ) Root Ferment Filtrate	Glycerin	5.00
<b>Phase VII</b>		
Fragrance	<b>AC Leucidal/Active Concepts, LLC</b>	0.50
Sodium Hydroxide	Lavender & Vanilla Sage 302669/ American Flavors & Fragrances	0.20
	NaOH 25% Solution	1.20

### Process Instructions:

**Phase I:** Charge water into main beaker and begin propeller mixing. A vortex should form. Begin heating to 70°C. Sift in ABS White Willow Bark Extract Powder. Charge Dermofeel PA-3. Sift in Ultrez 10. Continue mixing for 15 minutes.  
**Phase II:** Pre-blend and add to main. • **Phase III:** Switch to sweep mixing. At 70°C, add each ingredient.  
**Phase IV:** Begin force cooling. Add each ingredient at 50°C. • **Phase V:** Add at 50°C  
**Phase VI:** Pre-blend and add to main. • **Phase VII:** Add to main.



Tomorrow's vision ... Today!

+1-732-867-5040 • Fax: +1-732-867-5041 • [activeconceptsllc.com](http://activeconceptsllc.com)